

AcuActiv[®]

PREMIUM FREQUENCY THERAPY SPEAKER

PRODUCT GUIDE & SPECIFICATIONS



HOW TO USE

- 1 CONNECT**
Use the provided AUX cable to connect the frequency generator to the speaker.
- 2 POWER ON**
Press and hold the power button on the speaker until the indicator light turns on.
- 3 SELECT MODE**
Press "M" to switch between modes or play/pause your audio.
- 4 ADJUST VOLUME**
Use your device or the speaker controls to adjust the volume to your preference.



AUX IN CONNECTION

Insert the AUX cable into the speaker's AUX IN port and connect the other end to the frequency generator.



SPECIFICATIONS

- Version: \$2.05
- Lithium battery: 300mAh
- External magnetic speaker (Minimum order quantity of 100, no stock kept)
- Equipped with a one-in-one cable
- There are several types of prompt tones, which cannot be controlled

CABLE SPECIFICATIONS



- Specification: 3.0MM 1C Red + 26 strands 0.08 spiral shielding 80A black TPE
- Material: 80A black TPE + TPE plug
- Function: Microphone device audio input, sound card device audio input and output, super compatibility

POWERFUL HD SOUND – MULTI-FUNCTION



CLEAR
STEREO
SOUND



WIRELESS
BLUETOOTH



MINI
SIZE



TF CARD
MUSIC PLAY



USB
CONNECTOR



U DISK
PLAY



HIGH QUALITY
SOUND



LONG LASTING
BATTERY



COMPACT &
LIGHTWEIGHT



WIDE DEVICE
COMPATIBILITY